

CITY TURN | QUICK START GUIDE

DIMS | 18.25" W x 7.25" H

FRONT CLOSED VIEW - DO NOT PRINT



FRONT FLAT

GETTING TO KNOW YOUR SEAT

- 1 HEADREST/HARNESS ADJUSTMENT LEVER
- 2 ROTATION LEVER
- 3 LOWER ANCHOR STORAGE
- 4 FORWARD-FACING BELT PATH
- 5 TETHER
- 6 INSTRUCTION MANUAL STORAGE
- 7 RECLINE FOOT
- 8 RECLINE LEVER
- 9 FORWARD-FACING RAPIDLOCK
- 10 CUPHOLDER
- 11 REAR-FACING LEVEL INDICATOR
- 12 REAR-FACING RAPIDLOCK
- 13 REAR-FACING BELT PATH

LET'S GET STARTED

Please review this guide carefully prior to installation for tips, tricks and a map to your new City Turn™ car seat. For further information, reference the included instruction manual or visit babyjogger.com.

INSTALLATION CHECKLIST

See page 21 in the Installation Manual for complete installation instructions

- READ YOUR MANUAL.**
Always read your car seat manual prior to installing your car seat. Your car seat manufacturer should be your primary resource for information regarding your car seat.
- CUP HOLDER MUST BE INSTALLED.**
- INSTALLATION SHOULD BE TIGHT.**
Car seats should not move more than 1" (2.5 cm) at the belt path.
- CHECK THE LEVEL INDICATOR IN REAR-FACING MODE.**
- PLACE CHEST CLIP AT ARMPIT LEVEL.**
Not too high or too low.
- CHECK HARNESS HEIGHT.**
REAR-FACING: Harness straps should be at or below the child's shoulders.
FORWARD-FACING: Harness straps should be at or above the child's shoulders.
- PERFORM THE PINCH TEST IN THE SHOULDER AREA TO MAKE SURE THE HARNESS IS TIGHT ENOUGH.**
It is important that the harness is snug against your child's body.
- CHECK INSTALLATION OFTEN.**
Regularly inspect your seat's installation to ensure it is still tight and secure.

18 in
457.201 mm

6 in
152.4 mm

BACK FLAT

REAR-FACING INSTALLATION

For children 4-50 lb (1.8-22 kg)
Instructions for installing using your **vehicle's seat belt**.

1. Confirm your recline foot is in the rear-facing position by checking the label on the side of the foot. If it is not, rotate the recline foot located at the base of the seat to the rear-facing position. The recline foot is secure when it **"CLICKS"** into place.
2. Adjust recline foot between positions 1-3 by squeezing the recline lever and lifting the base to extend/retract the foot. Check that the recline foot touches vehicle seat and level indicator is in the correct blue zone.
For children over 40 lb (18 kg), MUST use recline position 1.
3. Squeeze rotation lever at the front of the car seat and rotate the seat to expose the rear-facing belt path.
4. Open the rear-facing RAPIDLOCK arm.
5. Route both vehicle lap and shoulder belt under the rear-facing belt guides and RAPIDLOCK arm. Buckle the seat belt.
6. Press down firmly near the front of the base. Pull on the shoulder belt to tighten while feeding the slack back in the retractor. Close the rear-facing RAPIDLOCK arm until you hear **"CLICK"**. **Notes:** Do not pull on the belt with excessive force. If the belt is too tight, you will not be able to close the RAPIDLOCK. Switch the retractor after the installation is complete to avoid a possible strangulation risk.
7. Rotate the seat back into place until you hear **"CLICK"** and confirm it is locked by pushing the seat side-to-side at belt path.
8. Verify the level indicator has not changed.

TIP: The American Academy of Pediatrics recommends your child ride rear-facing as long as possible, to the upper weight or height limit allowed by your car seat.

See page 20 for cup holder installation instructions. The cup holder **MUST** be installed.
See page 21 in the Installation Manual for additional Rear-Facing installation instructions.
See page 28-33 in the Installation Manual for Rear-Facing with **LOWER ANCHOR ATTACHMENT** instructions.

FORWARD-FACING INSTALLATION

For children 26.5-65 lb (12-30 kg), 49" (125 cm) or less
Instructions for installing using your vehicle's **seat belt and tether**.

1. Confirm your recline foot is in the forward-facing position by checking the label on the side of the foot. If it is not, rotate the recline foot located at the base of the seat to the forward-facing position. The recline foot is secure when it **"CLICKS"** into place.
2. Adjust the recline foot between positions 1-3 by squeezing the recline lever and lifting the base to extend/retract the foot.
For children less than 40 lb (18 kg), MUST use recline position 2.
3. Raise headrest to the highest position to clear the forward-facing belt path.
4. Remove tether from back of seat and lay it over the front of the seat.
5. Lift seat pad up and open the forward-facing RAPIDLOCK arm.
6. Route seat belt through the forward-facing belt path.
7. Route seat belt behind RAPIDLOCK arm. Buckle the seat belt.
8. Remove vehicle belt slack by pressing down firmly in the center of the car seat while feeding the vehicle belt into the retractor. **Notes:** Do not pull on the belt with excessive force. If the belt is too tight, you will not be able to close the RAPIDLOCK.
9. Close the forward-facing RAPIDLOCK arm until you hear **"CLICK"**. Switch the retractor after the installation is complete to avoid a possible strangulation risk.
10. Locate your vehicle's tether anchor per your vehicle's instruction manual. Attach and tighten the tether.

See page 20 for cup holder installation instructions. The cup holder **MUST** be installed.
See page 34 in the Installation Manual for additional Forward-Facing installation instructions.
See page 40-45 in the Installation Manual for Forward-Facing with **LATCH** instructions.

18 in
457.201 mm

6 in
152.4 mm

SPECIFICATIONS

LABEL NUMBER: NWL0001723671B
DESCRIPTION: INST-US-CS-CITYTURN QSG-ENG
MAGENTA DIE CUT DOES NOT PRINT