

USE AND CARE INSTRUCTIONS

⚠ **WARNING:** Not for use with carbonated beverages.
Do not freeze or microwave. Store with lid removed.

⚠ **CAUTION:**

- Not intended for children under 3 years of age.
- Product is NOT designed for hot liquids. Use only with cold liquids.
DO NOT use with carbonated or pulpy beverages.
- Prior to drinking, make sure the lid is properly threaded to the body and screwed completely.
- DO NOT overfill. Fill liquid just below the threading on the bottle.
- DO NOT use cleaners containing bleach, chlorine, abrasives, and/or harsh chemicals.
- DO NOT continue to use if product is damaged.

HOW TO USE

Unscrew lid,
sip from wide mouth.

- Leak-proof lid.





HOW TO CLEAN

1. Unscrew lid. Open lid.



- Top rack dishwasher safe.
- RINSE LID IMMEDIATELY AFTER EACH USE with warm water.
- If washing by hand, soak lid for 10 minutes in hot, soapy water. Hand wash body with warm water and a mild detergent.
- Rinse both lid and body thoroughly before use..



*Limited Lifetime Guarantee only applicable in the US & Canada. Visit GoContigo.com for details.