

Rubbermaid® Lock-Its™

7K90, 7K91, 7K92, 7K93, 7K94, 7K95, 7L03, 7L04, 7K96, 7K97, 7K80, 7K81, 7K82, 7L06, 7L55, 7K98, 7N05

Featuring four locking tabs that create an extra secure lid seal, this food storage system helps prevent spills. Plus, a built-in rubberized seal makes cleaning easy. Rubbermaid® Lock-Its™ feature The Easy Find Lid™ system- Lids snap to bases and other lids for easy storage and organization and graduated sizes nest together to take up less room in your cabinets.



Care & Use

To keep your new containers looking their best, we recommend the following:

- Remove label and wash before use.
- Use care when handling container with hot contents or after reheating in the microwave. Plastic is more flexible when warm.
- Made of microwave safe materials that can be used to reheat foods to a temperature comfortable for eating. These containers are not intended for cooking.
- Follow your microwave manufacturer's recommendation when defrosting or reheating foods.
- Excessive reheating or heating time may damage the container. Remove lid when in microwave to avoid dangerous steam build-up.
- To avoid staining or pitting, do not reheat food high in salt, oil, fat, sugar or tomato.
- These containers are not stain-resistant. Reheating foods containing tomato based products may stain the container. For improved stain resistance, try Rubbermaid® Premier™.
- Do not use in conventional oven, under browning elements or on stovetop.
- This item is made of materials that are safe for normal household dishwashers. Be sure that the item is secured so that it does not come in contact with the dishwasher element to avoid melting.
- This item is made of materials that are safe for freezer use. Please note that plastics are less flexible when cold or frozen and may break if dropped.
- Snap the bottom of the base to the top of the lid for easy storage and organization.