



AUTOSEAL® Stainless Steel Water Bottle
Use and Care Instructions



AWARNING

Hot contents can create internal pressure resulting in discharge of hot vapor. Always press button with mug in upright position away from face to properly release pressure before drinking.

WARNING

- Not for use with hot, carbonated or pulpy beverages.
- Prior to drinking, make sure the lid is properly threaded to the body and screwed on completely.
- Avoid accidental depressing of the AUTOSEÁL® button by keeping the button free and clear
 of other objects.
- DO NOT overfill. Fill liquids to just below the threading in the body.
- DO NOT microwave or freeze.
- DO NOT use cleaners containing bleach, chlorine, abrasives and / or other harsh chemicals.

USAGE RECOMMENDATIONS



TIP to drink



RELEASE BUTTON to Automatically Seal



CLEANING INSTRUCTIONS

- Wash thoroughly before first use.
- RINSE IMMEDIATELY AFTER EACH USE with warm water, pressing the AUTOSEAL® button so water flows through Drink Spout and Vent Hole.
- Lid is top-rack of dishwasher safe.
- · Hand-wash stainless steel body.



• To wash by hand, soak lid for 10 minutes in hot, soapy water. Hand wash body with warm water and a mild detergent. Rinse both lid and body thoroughly before use.









• ALWAYS STORE BOTTLE WITH LID REMOVED to allow parts to dry completely.





*Limited Lifetime Guarantee applicable in the US & Canada. See GoContigo.com for details

©2023 Contigo Brands. All Rights Reserved.

Should you have any questions about your purchase, please contact us at 1-888-262-0622 or GoContigo.com.