

Rubbermaid® Cake Keeper 3900

With a cover that fits tight to the base, the Durable Cake Keeper helps keep cakes and pies fresh. The base has molded-in centering rings and can be used as a serving tray when the lid is removed. Its see-through clarity lets you identify the contents immediately.



Care & Use

To keep your new containers performing at their best, please read the following:

- Remove label and wash before use.
- This item is made of materials that are safe for normal household dishwashers. Be sure that the item is secured so that it does not come in contact with the dishwasher element to avoid melting.
- Do not use utensils with sharp edges (i.e. knives) in the container, as they could scratch or scuff the container surface.